

2010 Trinary Mini-Cam Adjustment Chart - Iron Mace


1/1/10

PRODUCT:	INSERT	MODEL No.	xxxxxxxxxxxx	DWG.No.	xxxxxxxxxxxx	REV. c	MAT.	FINISH	xxxxxxxxxx
----------	--------	-----------	--------------	---------	--------------	--------	------	--------	------------

RAW MAT.:

2010 TRINARY MINI-CAM ADJUSTMENT CHART FOR THE IRON MACE.

WARNING: THIS BOW CANNOT BE DRAWN OR SHOT WITHOUT THE DRAW STOP INSTALLED, AND SET IN THE PROPER POSITION. IF NOT PROPERLY INSTALLED, THE BOW COULD LOCK UP AND CAUSE INJURY. REFER TO THE CHART FOR THE PROPER SETTING.



DRAW STOP MUST BE ON TOP WHEEL ON RH BOW. ALIGN LEFT SIDE OF DRAW STOP TO LENGTH NEEDED.

THE SETTING IN THIS DIAGRAM ARE FOR THE 80% LET OFF TO GET THE LOWER LET OFF IF REQUIRED MOVE DRAW STOP TO THE RIGHT(ON A RH AND LEFT AN A LH) OF THE PROPER LETTER TO ACHIEVE THE LOWER LET OFF. NEVER GO THE ANY OTHER WAY, THEN AS DESCRIBED OR THE BOW COULD LOCK UP AND CAUSE INJURY.

MINI DRAW MODULE

DRAW	IBO SPEED	DRAW STOP
A - 25.5	273/283	A
B - 26	277/287	B
C - 26.5	284/294	C
D - 27	296/306	D
E - 27.5	303/313	E

DWG. CHANGES

WARNING

THIS BOW CANNOT BE SHOT OR DRAWN WITHOUT THE DRAW STOP INSTALLED AND IN THE PROPER POSITION! IT IS BEST TO ADJUST THE DRAW STOP POSITION BEFORE SETTING MODULE POSITION.

<input checked="" type="checkbox"/> CRITICAL CHARACTERISTIC	<input type="checkbox"/> PLCS
CAD. DWG.	DO NOT SCALE DRAWING
DIMENSIONS: <input checked="" type="checkbox"/> INCH <input type="checkbox"/> METRIC	
TOLERANCES UNLESS SPEC. OTHERWISE	
TAPERED THREADS -BASIC- \pm THREAD	
ANGLES: \pm 3 FRACTIONAL \pm 1/32	
INCH .X = \pm .1	METRIC X = \pm 1 MM
.XX = \pm .01	.XX = \pm .5 MM
.XXX = \pm .005	.XXX = \pm .25MM
BOW RATING	

DESIGNED BY: RICHARD BATDORF
CHK'D. BY:
DATE:
SCALE: NTS
MAT. SUPPLIER

ANY REPRODUCTION OF THIS PRINT WITHOUT WRITTEN CONSENT FROM HCA IS STRICTLY PROHIBITED. ARE RIGHTS RESERVED.	
PRODUCT: TRINARY DRAW CHART	
MODEL NUMBER	
DWG. NO.	SHEET 1 OF 1
	REV.



Tel: 423-443-4185